

NY Thermal Inc.  
 Tel: (506) 657-6000  
 Toll Free: 1-800-688-2575  
 Fax: 1-506-432-1135  
 Web: www.nythermal.com  
 Email: info@nythermal.com

## 84745

# Grundfos Inlet/Pressure sensor, RPS4

### Applicable Boiler Models:

- Tx All Models
- Vmax All Models

### Kit Contents:

- 1 x Grundfos Inlet/Pressure Sensor with Sleeve
- 1 x Retaining Clip

### Tools Required:

- ¼" Nut Driver or Wrench

### Replacement Instructions:

- Turn off gas and power to boiler.
- Drain boiler of water.
- Remove retaining screw and swing control panel out of the way.
- To remove sensor press firmly and remove retaining clip and then pull out sensor.

### NOTICE

Ensure old O-ring is removed prior to installing new sensor.

- The pressure sensor is equipped with a rubber boot with integral O-ring. Prior to installing the new sensor remove the rubber boot and wet the sensor probe and rubber boot with water.

### NOTICE

Inlet sensor can only be installed one way, do not force into position.

- Refill boiler with water and purge excess air.
- Check for leaks.

